Item no. 2564

Bluetooth Wireless
Handsfree Car Kit

User's Manual

Bluetooth Wireless Handsfree Car Kit

By Wagan Tech

Thank you for purchasing Bluetooth Wireless Handsfree Car Kit by Wagan Tech. With normal care and proper treatment it will provide years of reliable service. Please read all operating instructions carefully before use.

About Bluetooth Speakerphone

The Bluetooth TTS Speakerphone is compatible with most Bluetooth mobile phones. The Text-To-Speech system announces instructions for the users in 5 different languages and also indicates the status of the Bluetooth device. It also announces the name of the incoming caller (or phone number if the contact is not loaded into the Speakerphones phonebook). Fully portable, it is an ideal wireless communication solution for in-car or office use within a maximum range of 10 meters. Built-in with Echo Cancellation and Noise Suppression, the Bluetooth Speakerphone provides you with impeccable sound quality in full duplex mode.

Make sure that your Speakerphone is fully charged before using it. Use only the charger provided - do not use chargers from any other devices as this might damage the device. A full charge is approximately 3 hours.

Charge Your TTS Speakerphone

(1) Connect to a mains charger or a USB charging cable to charge.
(2) When the LCD light indication is Red, the Speakerphone is charging.
(3) The LED light indication goes off when the device is fully charged.

Installing the battery



www.wagan.com

Appearance and Function



(1) Speaker
(2) Microphone
(3) LED
(4) Charging Socket (5-pin USB)
(5) Mode Button (Privacy handset & Mute)
(6) MFB Button (Multi-Function Button)
(7) Volume Increase (V+)
(8) Volume Decrease (V-)

Powering Up

(1) To turn ON the Speakerphone Press and hold the "MFB" button for four seconds and the flashing blue LED light indicator comes on ("Power On" is announced).
Note: Do not hold the button down for more than 8 seconds when turning the Speakerphone on or else it may switch to its pairing mode. If this happens, turn off the Speakerphone and repeat the process for turning the Speakerphone on.

(2) To Turn OFF the Speakerphone Press and hold the "MFB" button until the LED light indication goes off ("Power Off" is announced).

© 2008 Wagan Corporation.
All Rights Reserved.
Wagan and Wagan.com are trademarks used by Wagan Corporation.

Bluetooth Wireless Handsfree Car Kit

By Wagan Tech

Installation on the sun visor



Pairing

Pairing With Bluetooth Mobile Phone
Pairing is the process of connecting your Speakerphone with your mobile phone. Before using the Speakerphone with your mobile phone, you must pair both devices. If you wish to use your Speakerphone with a different mobile phone, you must reinitiate the pairing process with your intended Bluetooth mobile phone.

Pairing Speakerphone to Mobile Phone
1. Ensure that Speakerphone is turned off, switch to pairing mode by holding onto the "MFB" button till both Blue/Red LED lights appear ("Pairing phone please put your phone in pairing mode and enter PIN code 0000" is announced).
2. The LED lights will blink simultaneously in pairing mode.
3. Turn on the mobile phone and place it within 10 meters to the Speakerphone.
4. Initiates the mobile discovery feature on your mobile phone. Refer to your mobile phones user guide.
5. Enter the default pin code "0000", when prompted by your mobile phone system for pin code.
6. The blue LED blinks at a regular interval when both devices are successfully paired ("Pairing Successful" is announced).

WAGAN TECH
www.wagan.com

Connection Link /Between Speakerphone and Mobile Phone
Your mobile phone will always indicate a connection icon whenever it is paired to the Speakerphone. If the icon not present, a reconnection can be established by manually selecting the Speakerphone from your mobile phone's Bluetooth menu. If your Speakerphone is set as an authorized Bluetooth device on your mobile phone, an automatic reconnection can be established by pressing the Speakerphone's "MFB" button once.
Note: Your Speakerphone will be automatically switched off when it is disconnected from a paired device for more than 10 minutes. This special feature is incorporated to maximize your Speakerphones stand by talk time. To reinstate the connection, simply repeat the process for turning Speakerphone on.

Using the Speakerphone (Most functions will be audibly announced)

Making Call
You can initiate calls from your mobile phone, or directly from your Speakerphone using voice dialing commands (if this feature is supported by your mobile phone)

Making Calls from your mobile phone
Dial directly from your mobile phone. The call is automatically connected to your Speakerphone.

Receiving Calls
When your mobile phone rings, press the "MFB" button on the Speakerphone to connect the call.

Ending Calls
When you have finished your call, press the "MFB" button on the receiver to disconnect the call.

Rejecting Calls
Hold onto the "MFB" button for 3 seconds to reject an incoming call. .

Making calls using voice dialing (Dependent on mobile phone support)
Press the "MFB" button once and call out the name of the person for the call to be placed.

© 2008 Wagan Corporation.
All Rights Reserved.
Wagan and Wagan.com are trademarks used by Wagan Corporation.

Bluetooth Wireless Handsfree Car Kit
By Wagan Tech

Redial Last Outgoing Call
Press the "MFB" button twice and the call is connected.

Privacy Mode
In the midst of a conversation, press the "Mode" button once and the speaker volumes are automatically decreased to minimal levels where you can use the Speakerphone in the same mannerism as using any handheld phone.

Transferring Calls
Speakerphone to Mobile Phone - During a call, simply press both "V+" and "V-" buttons once and the call is routed to your mobile phone. Mobile Phone to Speakerphone - Press the "MFB" button once and the call is routed back to your mobile phone.

Adjusting the Volume
To increase the volume - Press the "V+" symbol volume button to increase volume by one level, repeat this procedure until you have reached the desired level. To decrease the volume - Press "V-" symbol button to decrease the volume by one level, repeat this procedure until you have reached the desired level.

Text-To Speech Language Options
Press the "V+" button for 3 seconds and the Speakerphone announces "Select Language". Repeat the process to select the desired language in the following order of English, French, Italian, German and Spanish.

Transferring Mode Phone's Phonebook to Speakerphone
Press the "Mode" button in the connecting status for 3 seconds and the Blue LED light indicator comes on. When the process is completed, the Speakerphone announces "Contacts Saved".
Note: The phonebook function varies from mobile phones and not every mobile phone supports this feature. Please refer to the compatibility list for details. Additionally, every new mobile phone connected will have its previous phonebook automatically deleted in the Speakerphone. Please repeat the process for Phonebook transfer on the intended mobile phone.

Removing Phonebook Entries
During standby mode, hold on to both "V+" and "V-" buttons for 3 seconds ("Phonebook Deleted" is announced) and the entire phonebook memory in the Speakerphone will be deleted.

Turning On/Off the Text-To-Speech Function
To toggle the TTS function On or Off, simply hold the "V-" for 3 seconds in standby mode ("Voice Prompt On" or "Voice Prompt Off" is announced to denote its current status) .

Restore to Default Settings
To restore your Speakerphone to its original settings, press and hold both "V+" and "V-" buttons for 10 seconds until the blue LED light indication flashes rapidly. Press and hold both "V+" and "V-" buttons for a further 3 seconds and the Speakerphone will power off automatically. This process is complete when Speakerphone announces "Set Factory Default Complete".

Care and Maintenance

(1) Do not expose the speakerphone to liquid, moisture or humidity, as it is not waterproof.
(2) Do not use abrasive cleaning solvents to clean the speakerphone.
(3) Do not place the speakerphone in high temperature, as it may result in an explosion.
(4) Do not expose the speakerphone to contact with sharp objects as this will cause scratching and damage.
(5) Do not attempt to disassemble the speakerphone, as it does not contain Serviceable components.
(6) If you do not use the speakerphone for long periods of time, be sure to store it in a dry place, free from extreme temperature, humidity and dust.

Safety Information

(1) Check local laws regarding use of a mobile phone and speakerphone while driving. If you use the speakerphone while diving, ensure your attention and focus remains on your responsibility of driving safety.
(2) Never allow children to play with the speakerphone. Small parts may be a choking hazard.
(3) Observe all signs that require an electrical device or RF radio product to be switched off in the designated areas. These could include hospitals, blasting areas, and potentially explosive atmospheres.
(4) Turn off your speakerphone prior to boarding an aircraft. Do not use your speakerphone in an aircraft.

© 2008 Wagan Corporation.
All Rights Reserved.
Wagan and Wagan.com are trademarks used by Wagan Corporation.

(5) Never place or store the speakerphone over the area of the automobile's safety airbag deployment, or it may cause serious injury when a safety airbag deploys.

Product Specifications:

Bluetooth Compliance	Bluetooth 2.0+EDR specifications
Operating Frequency Band	2.4GHz - 2.48GHz ISM band
Output Power	Class 2 Power Output, up to 10 meters
Support Profiles	Headset and Handsfree 1.5 Profiles
TTS Support Language:	English, French, Italian, German, Spanish
Support Multiple paired Device:	Up to 8 Bluetooth Phone can be paired
Stand-by Time	Up to 600 hours.
Talk time	Upto8- 10 hours
Battery Charging Time	About 3 hours
Charger Voltage:	DC5.OV 400mA
Battery Type	650mA BL-5B (Rechargeable Lithium Battery)

WAGAN Corp. Limited Warranty Registration Form

All WAGAN Corporation products are warranted to the original purchaser of this product.
Warranty Duration: This product is warranted to the original purchaser for a period of one (1) Year from the original purchase date, to be free of defects in material and workmanship. WAGAN Corporation disclaims any liability for consequential damages. In no event will WAGAN Corporation be responsible for any amount of damages beyond the amount paid for the product at retail. In the event of a defective item, please ship the item, prepaid, with a complete explanation of the problem, your name, address and daytime phone number. WAGAN Corporation will, at its option, replaces or repair the defective part. This warranty is void if the product has been damaged by accident, in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel or other causes not arising out of defects in materials or workmanship. This warranty is effective only if the product is purchased and operated in the USA and Canada and does not extend to any units which have been used in violation of written instructions furnished.
Warranty Disclaimers: This warranty is in-lieu of all warranties expressed or implied and no representative or person is authorized to assume any other liability in connection with the sale of our products. There shall be no claims for defects or failure of performance or product failure under any theory of tort, contract or commercial law including, but not limited to negligence, gross negligence, strict liability, breach of warranty and breach of contract.
Warranty Performance: During the above one (1) Year warranty period, a product with a defect will be replaced with a comparable model when the product is returned to WAGAN Corporation with an original store receipt. The replacement product will be in warranty for the balance of the one (1) Year warranty period.

- Please activate my limited warranty for WAGAN Corp.
- Enclosed copy of original sales receipt.

Name					
Mail Address					
Add'l Address					
City		State		Zip Code	
Item Purchased					
Store Name					
Date of Purchase					
Signature			Date		

All WAGAN Corporation Products must be registered within (30) days of purchased to activate this warranty.
Mail the complete registration form, along with a copy of the original receipt to:

Attn: Customer Service
WAGAN Corporation
3589 Yale Way, Fremont, CA 94538
Email: customerservice@wagan.com
Phone: (Toll Free) 1-800-231-5806 (Local) 1-510-490-9221
Hours of Operation: Monday through Friday 8:00 A.M. - 5:00 P.M. (P.S.T.)

© 2008 Wagan Corporation.
All Rights Reserved.
Wagan and Wagan.com are trademarks used by Wagan Corporation.